



QUICK HANDY PRODDER

CAT 45Q

Close quarter prodder Ideal for small stock and up close work Ergonomic sand-textured casing for easy handling and non slip Easy touch press button wrist strap 4 x "AA " alkaline battery Not Included Min. Peak voltage 3800V Equipped with high pitch sound Audible to animals

Instructions CAT 45Q

- 1. Read and understand all instructions before operating unit.
- 2. To change batteries: use 4 alkaline "AA" cell batteries: Loosen the screw from the end of unit to open the cover. Do not unscrew completely., Remove old batteries. Insert new batteries in accordance with the diagram inside the battery compartment. Close the end cover and tighten the screw. If unit is not used for extended periods of time, please remove the batteries.
- 4. To activate, slide the On-Off switch forward to On position. The On-Off safety switch helps prevent accidental discharge.
- 5. Press the power button while placing the contact point of the prod on the rear of the animal. For best results simply press, touch and release.
- 6. Testing the unit. The unit will emit a high pitch sound NOT NORMALLY AUDABLE TO ADULTS. If not in contact with the animal the unit will not discharge. If pressing power button without contact (open air) the unit will do nothing. There will be no sparks or noise. To test simply are the contact points across a piece of metal. Small sparks and cracking sound will be heard from the contact points indicating a fully functional unit.
- 6. Use caution when using Handy Prod on wet animals as there is a potential increase in intensity.
- 7. Operators are encouraged to minimize use of prodder
- 8.Trouble Shooting —Check the batteries to ensure they are not flat (use a battery tester if necessary) and are inserted in the right direction, If they are OK, then: Check all the metal contact points in the battery compartment. Be sure they are clean and free of corrosion.

